

# MageCollar Installation Instruction

## Note:

If the butyl tape has been in hot environment, it may be sticky and difficult to peel off the backing paper. If so, place the butyl tape in freezer for a few minutes or cold area for some time, it will be less sticky and very easy to peel off the backing paper.

**Tools required:** Flat tip screw driver, cleaning cloth

## Step 1

Remove old rubber collar if necessary and any debris. Wipe the pipe clean.



## Step 2

Slide MageCollar onto the pipe at desired position. Mark the top edge of MageCollar on the pipe. Remove MageCollar.



## Step 3

Apply butyl tape below the marked position on the pipe, wrap around the pipe and remove backing paper. Do not cut off butyl tape, instead overlap the butyl tape.

## Step 4

Slide MageCollar over the pipe carefully. Position the overlapped vertical MageCollar edges over the overlapped butyl tape so more butyl sealant can fill the cavity of the inside vertical edge of MageCollar.



## Step 5

Wrap the MageCollar around the pipe with hand as tight as possible.

## Step 6

Slide clamp just below the top edge of MageCollar and tighten it. Check the two locking pins at the bottom edges to make sure they are still locking the overlapped bottom edges and pinch them tight.



For help or more information, please contact Magerack Corporation

Phone: 951-200-5608

E-mail: [info@magerack.com](mailto:info@magerack.com)

Website: [www.magerack.com](http://www.magerack.com)